



Zone 17

A=26 - E=28

Zone 18

A=15 - E=16

Zone 10

A=46 - E=49

Zone 11

A=41 - E=45

Zone 9

A=46 - E=49

Zone 8

A=46 - E=51

Zone 16

A=26 - E=29

Zone 2

A=67 - E=73

Zone 3

A=57 - E=61

A=103 - E=113

Zone 1

A=56 - E=65

Zone 7

A=52 - E=57

Zone 4

Zone 12

A=20 - E=28

Zone 13

A=20 - E=22

A=50 - E=57

Zone 6

Zone 5

A=52 - E=57

Zone 14

A=20 - E=22

A=25 - E=28